

# ZL-210A Electronic Thermostat Instruction Manual

#### 1. Features

ZL-210A is an electronic thermostat for cooling. The device is ideally fitted to refrigeration equipment for cold storage.

#### 2. Main Function

- Temperature measurement
- Temperature display
- Temperature calibration
- Compressor delay protection
- Blustering when system warning
- Sensor problem warning

## 3. Main Specification

Temperature Sensor: NTC

Setting Range: -40 ~ 120 °C
 Display Range: -50 ~ 130 °C
 Working Temperature: -10 ~ 45 °C
 Storage Temperature: -30 ~ 70 °C

Power Supply: 185 ~ 245VAC 50/60HZ

Terminal Wire: <= 2 \* 1.5mm² or 1 \* 2.5mm²</li>
 Load Current: 3A 250Vac (Resistive load)
 Humidity: 5 ~ 85%RH (without dewing)

Case:
PC + ABS Fire Proof

Protection Degree: IP30

## 4. Operation Instruction

### 4.1 Display Indication

#### 4.1.1 Panel LED Indication

LED	On	Off	Blinking
MAX TEMP	Set max temperature	Set max temperature	
		(to be set)	
MIN TEMP	Set min temperature	Set min temperature (to	
		be set)	
COOL	Compressor on	Compressor off	Delay protecting now
TEMP	TEMP		

#### 4.1.2 Panel Digit Indication

Three red digits display the measured temperature and warning code.

Warning Code:

No.	Display Code	Warning Information
1	1 E1 Room sensor open circ	



1 - 011			
2	-E1	Room sensor short circuit	
3	Hi	Room temperature exceeds the MAX TEMP	
4	Lo	Room temperature exceeds the MIN TEMP	
5	EE	Data access error	
6	Err	Password error or max/min temperature set invalid	
7	Frd	Forced cooling	
8	UnL	Restore the default password "11"	

#### 4.2 Keypad Operation

#### 4.2.1 Set Max and Min Temperature

- Press 【SET】, MAX TEMP LED will be on, and the digits will show the current max temperature. Press key
- Press 【SET】 again, we can set the min temperature limit.
- Keeping depressing 【SET】 for 3 seconds, or do not press any key for 30 seconds, the device will leave the temperature testing mode.
- The factory setting: max temperature is -15℃, min temperature is -18℃.
- The MAX TEMP must be higher than the MIN TEMP 1 °C, otherwise could not be saved.

Note: Only after the [ SET ] being depressed for three seconds, will the set data be confirmed and saved.

#### 4.2.2 Set System Parameters

#### **Enter Into System Parameter Setting Mode**

Keep depressing 【SET】 for three seconds, digits show "POO". Input password + 【SET】. If correct, enter into the mode, else return.

After enter into the mode, the display shows "U01". Press 【 ▲ 】 or 【 ▼ 】 to select the parameter code.

Press 【SET】 will show the parameter value. Then press 【▲】 or 【▼】 to set this parameters, and press 【SET】 to return.

The factory setting: password is "11".

#### 4.2.3 Exit the Mode

Keep depressing "SET" for three seconds, the set parameters will be saved, the mode exits.

Or do not press any key for 30 seconds, the mode exits, and the set parameters are not saved.

#### Parameter Code and Description Table:

No.	Parameter code	Function	Range	Explain	Factory setting
1	U10	Compressor power on delay time	1 ~ 100min		3
2	U11	U11 Compressor MIN continuous work time			3
3	3 U12 Compressor run frequency		0 ~ 8	0: Disable	5
4	U20	Room temperature sensor calibration	-9.9 ~ +9.9		0
5	U50	High-temperature warning deviation value to Max Temp	0~60℃	0: Disable	0
6	U51	Low-temperature warning deviation value to Min Temp	0~60℃	0: Disable	0
7	U52	Over-temperature warning delay time	1 ~ 180min		30
8	U53	First over-temperature warning delay time after power supply	0~180 hour	0: Disable	2
9	U62	Buzzer warning	0~1	0:Warning off	0



				1:Warning	
				on	
10	U99	Password	0~99		11

## 5. Control Function Description

#### 5.1 Compressor Control

- When the temperature ≥ "MAX TEMP", and the time that the compressor has stopped ≥ "the valve of U10", the compressor starts.
- When the temperature ≤ "MIN TEMP", and the time that the compressor has run ≥ "the valve of U11", the compressor stops.
- Compressor emergent on

Press and hold "▼"key for five seconds, the compressor will power on if the following meets:

- controller in non-defrosting status
- controller in non-dropping water status
- the compressor stops

In compressor emergent on status, press and hold "▼" key for five seconds, the mode exits.

#### 5.2 Compressor Delay Protection

- After power supply, the compressor is able to start only after the time (U10) has passed.
- After the compressor stops, it is able to restart again only after the time (U10) has passed.
- After the compressor starts, it is able to stop only after the time (U11) has passed.

#### 5.3 Temperature Sensor Failure Protection: Protected Running Mode

 When the room temperature sensor fails, the system will automatically run in the protected running mode. In this mode, the compressor will run and stop with the period of 30 minutes. Compressor works for U12\* 3 minutes, stop for { 30 - (U12\* 3) } minutes.

Note: If U12=0, system stops when sensor fails

#### 5.4 High- temperature and Low-temperature warning

- When the test temperature ≥ "MAX TEMP"+ "U50", and the time reaches to "U52 or U53",high temperature warning starts.
- When the test temperature ≤ "MIN TEMP"+ "U51", and the time reaches to "U52 or U53", low temperature warning starts.

#### 5.5 Temperature Calibration Function

When there is tolerance between the measured temperature and real temperature, set parameter U20 and u21 to calibrate. The calibration range is ±9.9°C. while set the parameter, the step is 0.1°C for every key press. Keep pressing, the set data will increase/decrease quickly.

#### 5.6 Restore the default password

When password forgotten, the following way can restore it:

Press and hold "▲" and "▼" key, turn on the power supply, the device displays "UnL", after three seconds, buzzer sounds, system auto restores the default password "11".

#### 6. Controller Installation

Avoid to installing the device in the following environment: 6.1 Warning

- Relative humidity is greater than 90%, or possibly dewing.
- Strong vibration.
- Possibly be dropped, or within fog.
- Exposed to eroding and polluting gases (such as: air containing sulfur and ammonia, salty fog, smoky mist) to

